



## **MODEL 1018-14**

**Installation Instructions**

### **\*\*\*\* WARNING \*\*\*\***

**Please thoroughly read the product warning below before installation to provide for a safe work environment.**

1. When fastening the enclosure lid, be sure that the screws are completely fastened to prevent the lid from accidentally falling

# Installation Instructions

## Model Numbers 1018-14

### Assembly Components:

- Wall / Ceiling Enclosure, Model 1018-14 Assembly – 1 each
- Cisco Mounting Bracket – 1 each
- T-Bar Bracket – 1 each
- Cisco AP Bracket – 1 each
- Wi-Fi Label – 1 each
- #8 Sheet Metal Screws – 2 each
- #8-32 x 1/4" Screws - 4 each

If any of these items are missing, contact your Oberon representative.

**Step 1** – Remove the enclosure lid and mark the drill points for securing the enclosure to the wall or ceiling. Drill out any material in the back of the base for routing cables to the access point. Fasten the enclosure to the surface using the pre-drilled hole locations and wall anchors or other hardware.

**Note:** Any holes drilled through the enclosure must be sealed to maintain water tightness.




Figure 2

**Step 2** – A surface mount box (or biscuit jack) and equipment cord can be conveniently mounted inside the Model 1018. Use an adhesive backed surface mount box. Consider bend radius of horizontal cable and equipment cord when attaching the surface mount box.




Figure 4

**Step 3** – Fasten the universal T-Bar Bracket or Cisco Mounting Bracket to the inside of the enclosure using the provided #8 sheet metal screws.




Figure 1

**Step 4** – Secure the access point to either the T-Bar Bracket, or Cisco Mounting Bracket. #8-32 x 1/4" screws are provided to fasten the Cisco AIR-BRACKET-1 or -2 as well. If a surface mount box is installed, attach the patch cord from the surface mount box to the access point. Otherwise, attach the Ethernet cable directly to the access point.




Figure 3




Figure 5

**Step 5** – Apply the WiFi Label to the clean and dry cover. Fasten the lid with the side clips. Installation is now complete.